

User Manual T200C2



High Performance Tactical Flashlight
<http://www.eagletac.com>

EAGTAC T200C2 packs big lumen output in a compact, tough and grippy body. It offers versatile user interface, highly efficient synchronous buck circuit, and rich accessories like no other. Be crazy lumen with you in the dark.

Quick Specifications

LED	CREE XM-L2 LED
Runtime (2*CR123A)	0.8 to 100+ hrs
Runtime (1*18650)	1.5 to 150+ hrs
Output	3
Circuit	C3000 TS
Batteries	1x18650 or 2xCR123A
Voltage	2.7V-8.4V



WARNING - Lithium and Li-ion batteries can explode or cause burns if disassembled, shorted, or exposed to high temperature. Do not mix with used or other battery types or install backwards.

Quick Start Guide

1) Unscrew the tailcap and insert new batteries (w/ protrude top) to use. Ensure positive terminals is facing the LED and the ring that holds the pocket clip is tighten. Replace tailcap and tighten snugly.



Basic ON and OFF

Switch on/off the T200C2 by pressing the tailcap switch boot until it clicks. To momentarily switch on the light, apply light pressure on the switch boot.



Adjusting output level

Twist the head to select between three output levels. You can pre-select the desired output level before turning on the flashlight.



Energy saving feature

This preveres the runtime by reducing LED output current by 10% after 200 seconds at turbo (100%) mode.

Battery Safety Precaution

All EAGTAC flashlights are designed to use button-top battery with protruding positive terminal. For rechargeable li-ion battery, use only EAGTAC li-ion battery, or other protected li-ion battery with compatible length and diameter. Always ensure the battery outer wrapping is complete. Broken battery wrapping may lead to short circuit and may damage to the flashlight.

Lithium and Li-ion battery can explode or cause burns if disassembled, shorted, or exposed to high temperature. Do not mix new and used batteries. Do not mix batteries with different brand, capacity, voltage, or install batteries backwards. When the output starts to dim (this implies battery is almost drained), replace the batteries. Do not drain the batteries completely especially when you're using two (or more) batteries in series.


Maintenance

Periodically clean the thread and o-rings with a lint free cloth and apply a thin coating of EAGTAC synthetic PTFE lubricant to the o-rings (not the machined thread).

Clean the battery contact, gold plated signal pins, PCB board contact area, and machined thread with a lint free cloth. Use a small drop of Deoxit red cleaner solution (D100L series) to slightly lube them for more reliable operation and smoother mode switching experience.

"Deoxit" is a trademark of Caig Laboratories, Inc.

Periodically clean and apply Deoxit red to ensure smooth mode switching and good long term reliability.



Troubleshooting - Flashlight does not turn on or fails to switch between outputs normally:

- 1) Always replace batteries
- 2) Ensure tailcap is tight
- 3) Clean all conductive contacts (see maintenance section)
- 4) Check battery polarity

"No Hassle" EAGTAC Warranty

For repair, replacement, or other inquiries contact your EAGTAC dealer. You can also reach our customer support via email at support@eagletac.com.

We warrant our flashlights to be free from defects in workmanship and materials. We will repair, replace at our option, without charging any product or part which is found to be defective under normal use within 120 months from the date of purchase with the proof of purchase.

Electronics, chargers and rechargeable batteries are covered for a period of 12 months with purchase receipt. Such repair or replacement shall be the purchaser's sole and exclusive remedy under this warranty. Normal wear and tear including batteries draining is not covered, nor is damage resulting from modification, misuse, abuse, neglect, faulty battery, battery leakage, improper maintenance or repaired by anyone other than EAGTAC or authorized dealer.